

# Broil King®

---

ASSEMBLY MANUAL & PARTS LIST - MANUEL DE MONTAGE & LISTE DE PIÈCES

---



**Broil King®**

**S100 IR BURNER**

804724

804727

---

RETAIN FOR FUTURE REFERENCE - VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE


---

*Onward*  
SINCE 1906  
**MANUFACTURING COMPANY**  
585 KUMPF DRIVE LIMITED  
WATERLOO, ONTARIO, CANADA  
N2V 1K3


info@omcbbq.com  
1-800-265-2150

70084-S101 REV B 03/24


1




# 2a




# 2b




3a




4



5a





6a




# 7

(1)



8



## PARTS LIST / LISTE DES PIÈCES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>DESCRIPTION</u>	<u>804724</u>	<u>804727</u>
1	73009-103A	TRIM ASSEMBLY	ASSEMBLAGE DE BORDURE	1	1
2	73170-023	FRONT / REAR TRIM	BORDURE - BRÛLEUR DE CÔTÉ	2	2
3	73149-213	SIDE TRIM	BORDURE - BRÛLEUR DE CÔTÉ	2	2
4	73131-233	DIVIDER TRIM	BORDURE - DIVISEUR	1	1
5	73139-233	CONTROL COVER	PANNEAU DE CONTROLE	1	1
6	Y-12130	CORNER CAP - 90 DEGREE	BOUCHON	4	4
7	22001-163	CONTROL BEZEL	MONTURE DE CONTROLE	1	1
8	22001-668	CONTROL KNOB	BOUTON DE CONTROLE	1	1
10	23001-79	GRID	GRILLE	1	1
11	73001-203	SIDE BURNER LID	COUVERCLE LATÉRAL	1	1
12	20395-4A	SIDE BURNER	BRULEUR DE COTE	1	•
	20395-7A	SIDE BURNER	BRULEUR DE COTE	•	1
13	70792-E20LP	VALVE ASSEMBLY - LP	SOUPAPE	1	•
	70792-21NG	VALVE ASSEMBLY - NG	SOUPAPE	•	1
14	10153-27A	SPLITTER HOSE ASSEMBLY	TUYAU	1	1
15	10342-244	ELECTRONIC IGNITOR	ALLUMAGE ÉLECTRONIQUE	1	1
16	10342-T14	ELECTRODE WIRE	FIL D'ÉLECTRODE	1	1
18	10111-19A	REGULATOR CONNECTOR HOSE	TUYAU	1	1
20	Y-29301	SCREW - #10-24 X 1/2	VIS - #10-24 X 1/2	8	8
21	Y-29304S	SCREW - #10-24 X 3/8	VIS - #10-24 X 3/8	4	4
22	S21127S	SCREW - #8-32 X 7/16	VIS - #8-32 X 7/16	8	8
23	18670	SCREEN	ÉCRAN	1	1
24	Y-29307	NUT - #10-24	ECROU - #10-24	2	2
25	10111-14A	CONNECTOR	TUYAU	1	1
26	23039-274	GREASE PAN SUPPORTS	GUIDE DU BAC A GRAISSE	2	2
27	22009-901	GREASE PAN	CUVETTE A GRAISSE	1	1
29	Y-12678	BEZEL STOP	OBTURATEUR	1	1
30	Y-12674	KNOB ADAPTER	ADAPTATEUR DE BOUTON	1	1

