


Exploded View and Replacement Parts



Blaze Part Number: Reference Guide					
1.	BLZ-20KMDO-006	10.	BLZ-20KMDO-001		
2.	BLZ-20KMDO-009	11.	BLZ-20KMDO-011		
3.	BLZ-20KMDO-005	12.	BLZ-20KMDO-010		
4.	BLZ-KMDO-SSHAND	13.	BLZ-20KMDO-008		
5.	BLZ-20KMDO-004	14.	BLZ-20KMDO-013		
6.	BLZ-20KMDO-007				
7.	BLZ-20KMDO-012				
8.	BLZ-20KMDO-003				
9.	BLZ-20KMDO-002				